


PARTS LIST

<u>Description</u>	<u>Qty.</u>
Fender Tips, Front and Rear of Front Fender	1Set
Alcohol Wipe	2



No Tools Required
Supplies Required to Clean Front Fender

INSTALLATION

Identify the Tips. Both Tips are made for the Front Fender. The Tip with the smooth surface will fit the Front Edge of Fender. The Tip with the scalloped surface will fit the Rear of Front Fender.

NOTE: Allow time for the 3M® brand quality tape to cure for 24 hours at 70-90° F (21-32° C) before washing, waxing or riding the motorcycle.

1. Thoroughly wash fender where Fender Tip will be installed. After cleaning, use an alcohol pad to wipe the area where Fender Tip will mount.
2. Remove the red backing from the adhesive on the inside of the Fender Tip.
3. Position the Fender Tip on the Fender. Adjust the position now.
4. When the Fender Tip is satisfactorily positioned, squeeze the Fender Tip against the Fender.
5. Repeat the above steps for the remaining Fender Tip.
6. Allow 24 hours for the adhesive to cure before washing, waxing, or riding the motorcycle.

CARE and MAINTENANCE: Clean and polish with any quality, Chrome Cleaner/Polish.

Front Fender Tip



Rear of Front Fender Tip

