


INSTALLATION AND OWNER'S MANUAL

Drive Shaft Cover Z9101 for use with R1200C Models.



10mm Socket Short Extension Socket Wrench 10mm Wrench

NOTE: Right and Left side of Motorcycle is determined while sitting on the bike.

PARTS LIST for Drive Shaft Cover Z9101

<u>Index</u>	<u>Part No.</u>	<u>Description</u>	Qty.
1	37-370810-000	Cover, Drive Shaft	1
2	37-370811-000	Cover, Rear Brake Hose	1

PREPARATION

- 1. Remove the right hand brake hose cover from the top of the drive shaft. Retain nuts.
- 2. Observe the brake hose and wires in their rubber protector.



- 1. Position drive shaft cover in place over threaded studs. Be sure cover is against drive shaft and there are no hoses or wires caught between cover and drive shaft. Figure 1.
- **2.** Place wires and brake hose cable in rubber protector in the same manner as originally assembled. Figure 2.
- **3.** Place chrome hose cover over bundled wires and secure with cap nuts. Figure 3.
- 4. Tighten cap nuts to 7Nm (5.1 ft lbs)

MAINTENANCE

The high quality chrome finish of your ZTechnik drive shaft cover can be maintained with any quality chrome cleaner and /or polish.





Figure 1



Figure 2



Figure 3

ZTechnik PO Box Maywood, IL 60153-0158 USA

708-343-0400 / Fax: 708-343-0625 / www.Z Technik.com / e mail: info@Z Technik.com

©2001 National Cycle, Inc.

Page 1 of 1

10-117708-000 4/01