

Read these instructions carefully and thoroughly before beginning work.

<u>Contents of Kit</u> Windscreen, Lexan FMR polycarbonate	<u>Qty.</u> 1
Bag 515	
Cap, aluminum	3
Screw, Flat HS M5 x 40	2
Screw, Flat HS M5 x 30	1
Bushing, Rubber	3



Figure 1



Figure 2



Tools Required:

TX25 Screwdriver. 3mm Hex Key

INSTALLATION

1. Remove the 3 original Torx screws from existing BMW windshield. Screws will not be reused. Figure 1. (TX25 Screwdriver)

2. Remove the original BMW windshield. The U shaped plastic piece beneath original windshield will fall free. You will re-use this piece with the installation of the ZTechnik windshield.

NOTE: To properly install this shield on an F 650 GS (NON-DAKAR Model), you will need to purchase the U-shaped plastic piece from your BMW dealer. The BMW part number is 71-60-7-653-849.

3. Install 3 rubber grommets into new ZTechnik windshield holes. **Figure 2.**

Install ZTechnik Windshield

4. Reposition U shaped plastic piece. Start at the lower center hole and install the ZTechnik windshield with 1 Aluminum Cap and the M5x30 Screw (short screw.) **Figure 2. (3mm hex Key)**

5. Install 2 remaining Aluminum Caps and the M5x40 Screws at the remaining hole locations, left and right side. **Figure 3. (3mm hex Key)**

6. Firmly tighten all screws.

1110/

MAINTENANCE

To clean the screen, wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths. **Paint, glue residue or grease removal:** Moisten cotton with Naphtha or Turpentine followed by a wash as above. Apply a high quality plastic cleaner. This will leave a protective coating on the screen making future cleanings easier. Do not clean polycarbonate in hot sun or high temperatures. *Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen or penetrate between the chrome brackets as permanent damage will result!*

 ZTechnik
 PO Box 158 Maywood, IL 60153-0158 USA

 708-343-0400
 / Fax: 708-343-0625
 / www.Z Technik.com / e mail: info@Z Technik.com

 e, Inc.
 Page 1 of 1
 10-117757-000 04/04 Rev. A. 10/04

©2004 National Cycle, Inc.