



Attention




Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



TOOLS REQUIRED:
Torx Wrench, T25



Right and left side of motorcycle is determined while sitting on the bike.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	Windshield, Quantum Coated Lexan® polycarbonate	1

INSTALLATION



Retain all fasteners, as they will be reused.

1. Remove the 4 screws holding the stock windshield to the motorcycle. **(Torx Wrench, T25)**

2. Remove the four wellnuts with washers from the original windscreen.



Washers may separate from wellnuts. Do not loose washers.

3. From the front of shield, install wellnuts into ZTechnik windscreen. Replace washers into wellnuts if necessary.

4. Place ZTechnik Windscreen into position on motorcycle. Reinstall the original bolts through the fairing and into wellnuts.

5. Tighten the bolts firmly. **(Torx Wrench, T25)**

MAINTENANCE

Cleaning: Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

Paint, glue residue removal: Moisten cotton with a small amount of Naphtha or Turpentine followed by a wash as above. Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

View ZTechnik® R 1200 ST products at www.ZTechnik.com

CARBON FIBER KITS * EXHAUST SYSTEMS * STORAGE POD
TECHMOUNT STANDS